


LEG SEPARATORS



MATERIALS

- A PVC tube (50mm thick)
- B Lariat (1")
- C Velcro (1")
- D Rivets
- E Barrette
- F Buckle

HOW TO FABRICATE

- 1 Cut 2 small pieces of PVC tube (14cmx4cm).
- 2 Heat the PVC pieces at a temperature of 120° and then bend them and give them the shape with a 1" tube.
- 3 Make a hole at one of the ends of the PVC pieces.
- 4 Cut 2 pieces of lariat of 86cm and 2 pieces of 13cm.
- 5 Cut 4 pieces of soft velcro and 4 pieces of hard velcro of 14cm and sew them to one end of the largest piece of lariat. First sew the soft velcro and then the hard velcro.
- 6 Sew the barrette to the lariat where the hard velcro ends and pass the buckle through.
- 7 Pass the small piece of lariat through the other end of the buckle and sew it.
- 8 Make a hole at the end of the small piece of lariat.
- 9 Put together the PVC pieces and the small lariat pieces with rivets.
- 10 Adjust the leg separators to the lower "C" frame of the gait trainer as shown in the image.